Flow Chart Menu DILAN2150 / Only DVB-S V4.0 (31/05/2005)



Flow Chart Menu DILAN2150 / DVB-S & Analog V4.0 (31/05/2005)



Different operation modes:
DVB-S: Digital section switched on; analog section switched off
A/V&dBuV: Analog section switched on; digital section switched on for level measurement
A/V: Analog section switched on; only for A/V-repetition (monitor); no level measurement; digital section switched off (stand-by mode)